

> Usage Instructions

- With occupant seated, grasp the buckle and position it over the center of the body
- Grasp the free connector and insert it into the buckle in the port opposite of the connector that is fixed in the buckle.



> Usage Instructions

With buckle now connected, pull the buckle down towards occupant's lap.



> Usage Instructions

With buckle centered over occupant, pull loose end of lap belt directly away from buckle to tighten restraint low and tight across the occupants lap.



> Usage Instructions

Do not tighten lap belt by pulling loose ends of lap belt before positioning buckle down near occupants lap.



> Usage Instruction Video: Lift-Lever Buckle with Attached Shoulder Harness

Video demonstrations shows the correct and incorrect way to fasten and adjust the restraint system.

CORRECT




INCORRECT



> Usage Instruction Video: Rotary Buckle with Attached Shoulder Harness

- Video demonstration shows the correct way to fasten and adjust the restraint system.
- Use the same methodology as previously depicted with the lift-lever buckle.



> Usage Instruction Video: Rotary Buckle with Separate Shoulder Harness

- Video demonstration shows the correct way to fasten and adjust the restraint system.
- Since the shoulder harness attaches separately, the lap belt is adjusted low and tight, and then the shoulder harness is attached.

